
# M490G Electromagnetic Locks



Installation Instructions

# **Swinging Application**



For swinging application, go to page 2

#### For sliding application, go to page 5

#### **FEATURES**

#### Magnetic Bond Sensor (MBS)

Detects proper bond between magnet and armature. It can be monitored remotely.

#### **Door Position Switch (DPS)**

Indicates whether door is open or closed. This feature is used in conjunction with the MBS.


### **ELECTRICAL SPECIFICATIONS**

Model	Amps (12VDC) Per Lock	Amps (24VDC) Per Lock	Holding Force (Ibs) Per Lock
M490G	0.650	0.350	1500


# **Sliding Application**


### **1** PLACE TEMPLATE AND MARK HOLES

- Place template on gate and post surfaces as marked on template.
- Mark holes and prepare them per template.





# **2** INSTALL MAGNET ASSEMBLY TO NON-MOVING POST





# ${f 3}$ install armature to moving part of gate






## 3e

Adjust Armature • Close gate.


- Press armature to fully engage with magnet.Fully tighten two screws and set screw to lock position.




For Wiring Installation, see page 8.


## **1** PLACE TEMPLATE AND MARK HOLES

- Place template on gate and post surfaces as marked on template.
- Mark holes and prepare them per template.




# **2** INSTALL ARMATURE TO MOVING PART OF GATE





## **3** INSTALL MAGNET ASSEMBLY TO NON-MOVING POST




#### Attach Magnet to Bracket

· Slide magnet assembly onto mounting bracket.

2x


• Secure magnet with two screws.



For Wiring Installation, see page 8.

### WIRING INSTALLATION

# **1** ATTACH WIRING PER INFORMATION SHOWN



# **2** CONNECT CONDUIT TO LOCK

